

Running gear/cart/trolley

Ordering Information

Stock No.	Description	XMT® 350	XMT® 450	XMS® 425	Maxstar®/Dynasty® 400	Maxstar®/Dynasty® 800
4 wheel large running gear						
058035011	4 wheel large running gear					
156031088	Top shelf (for wire feeder)			-	-	-
156031087	Middle shelf					-
028066300	Swivel for wire feeder (XMS & MigMatic®)	-	-		-	-
4 wheel small running gear					Maxstar®/Dynasty® 210	Dynasty® 280 CC/CV
058035010	4 wheel small running gear					
199403	Foot pedal holder for TIG running gear small					
191875	Torch hanger for TIG running gear small					
156031089	Side bracket support for suitcase feeder			-	-	
MigMatic® Cart					MigMatic® S400i	MigMatic® S400iP
058066141	MigMatic® Cart					
028066300	Swivel for wire feeder (XMS & MigMatic®)				Included	
MigMatic® Feed						
028066304	Wheel kit for MigMatic® Feed					
Running gear for XMT® 350						XMT® 350
018035031	Running gear XMT® 350					
2 wheel trolley		SI 160	STI 160	STH 160	MPI 220P	Maxstar®/Dynasty® 210/280
058035012	2 wheel trolley					

- Required for Air&Water cooled
- Required for Air cooled only
- Option

Stock No.	Description					
Running gear for XPS Series					XPS 350	XPS 450
058066064	Single Cylinder Running Gear					
058066065	Single Cylinder + Cooler Running Gear					
4 wheel cart for Syncrowave® 300/400					Syncrowave® 300	Syncrowave® 400
301601	Syncrowave® 300/400 4-wheel cart (for air-cooled Syncrowave® only)					
Running gear		Dimension™ 650 CC/CV	XMT® 450 MPa	XMT® 450 CC/CV	XMT® 350 FieldPro™	XMT® 350 FieldPro™ with Polarity Reversing
058035016	Running gear					
Trailers for Big Blue® 400X Pro						
018035030	Road trailer Big Blue® 400X Pro (FR)					
301338	HWY-225, trailer engine drive for field only (not certified for roads)					
Running gear for Continuum™ & Auto-Continuum™						
301264	Running gear Continuum™ & Auto-Continuum™					
Running gear for ProHeat™ 35						
195436	ProHeat™ 35 Running Gear					

- Required for Air&Water cooled
- Required for Air cooled only
- Option